

FIBRE UBB FRITZBOX SETUP GUIDE

*Power ON the FritzBox with the power cable provided.

NOTE- the power supply is unique to the FritzBox, please do not use 3rd party supplies, contact UBB for replacement parts if damaged.

*Once powered ON plug the Ethernet cable from **LAN1** of the FritzBox to **LAN1** of the Fibre IMG/ONT (unless otherwise advised by UBB).

Please do not use the DSL port, this is for DSL/VDSL services only.

*Wi-Fi details are found on a sticker at the front of the FritzBox.

*If you need to login to the FritzBox to change any settings, this can be accessed from your web browser with the following:

Web Address: 192.168.1.1

Username: admin

Password: admin123

Please don't reset the unit as your connection will no longer work.

PHONE:

If you have a VoIP landline add on with us, plug the line cord provided into the **FON** port and the other end of the line cord into your existing phone.

If you have any questions, please contact our helpdesk on 0800 000 945.

FIBRE

